



# GV-VS2800 8CH H.264 TVI 1080p Video Server



- H.264
- 8-channel TVI 18 fps at 3 MP and 15 fps at 4 MP
- 8-channel TVI 1080p / 720p and analog 960H / D1 real-time video
- 12V DC
- Tampering Alarm
- USB HDD Storage
- UMTS / 3G / 3.5G / 4G
- Automatic switch between WiFi and 3G / 4G
- Smart streaming
- Supports over 50 PTZ models
- 29 languages on Web interface
- HD-TVI (1.0 / 2.0 standard)
- ONVIF (Profile S) conformant

\*Smart streaming is only supported by GV-DVR / NVR V8.7.0.0 or later and GV-VMS V16.10.3 or later

GV-VS2800 is a powerful H.264 Video Server with compact size and supports 8 channels of TVI 18 fps at 3 M and 15 fps at 4 M, 1080p / 720p and analog 960H / D1 real-time video. It can be fully integrated with GV-DVR / NVR / VMS to form a powerful IP surveillance solution. GV-VS2800 converts analog signals into high-resolution digitized images up to 4 megapixels and supports over 50 PTZ models to fulfill various project demands. It can record videos to a local USB storage, performing as a compact video recorder. It is also able to trigger Tampering Alarm alerts when cameras are tampered with, which can prevent criminal activities.

### **Specifications**

| Video            |        |             |   |
|------------------|--------|-------------|---|
| Video Standard   |        |             | NTSC, PAL   |
| Video Input      |        |             | 8 channels  |
| Compression      |        |             | H.264   |
| Signal Type      |        |             | TVI / CVBS  |
| Frame Rate       | NTSC   |             | 18 fps per channel at 3 MP; 144 fps in total for 8 channels   |
|                  | NISC   |             | 15 fps per channel at 4 MP; 120 fps in total for 8 channels<br>30 fps per channel at 1080p; 240 fps in total for 8 channels |
|                  |        |             | 18 fps per channel at 3 MP; 144 fps in total for 8 channels   |
|                  | PAL    |             | 15 fps per channel at 4 MP; 120 fps in total for 8 channels<br>25 fps per channel at 1080p; 200 fps in total for 8 channels |
| Resolution       | NTSC   | Main Stream | 2560 x 1440, 2048 x 1536, 1920 x 1080 (Default), 1280 x 720, 640 x 360, 448 x 252 for TVI Signal                            |
|                  | HD     | Sub Stream  | 640 x 360, 448 x 252 (Default) for TVI Signal   |
|                  | NTSC   | Main Stream | 960 x 480, 720 x 480 (Default), 480 x 240, 360 x 240 for Analog Signal  |
|                  | SD     | Sub Stream  | 480 x 240, 360 x 240 (Default) for Analog Signal  |
|                  | PAL    | Main Stream | 2560 x 1440, 2048 x 1536, 1920 x 1080 (Default), 1280 x 720, 640 x 360, 448 x 252 for TVI Signal                            |
|                  | HD     | Sub Stream  | 640 x 360, 448 x 252 (Default) for TVI Signal   |
|                  | PAL    | Main Stream | 960 x 576, 720 x 576 (Default), 480 x 288, 360 x 288 for Analog Signal  |
|                  | SD     | Sub Stream  | 480 x 288, 360 x 288 (Default) for Analog Signal  |
| Video Streaming  |        |             | Configurable frame rate and bandwidth, Constant and variable bitrate  |
| Video Adjustment |        |             | Brightness, Contrast, Saturation, Hue, Sharpness  |
| Dual Streams     |        |             | Yes   |
| Coaxial Cable    | Recomn | nended Type | 5C-FB or above  |
|                  | Maximu | ım Length   | 300 m (984 ft)  |





| Audio                  |         |  |
|------------------------|---------|--|
| Audio Input            |         | 4 ports, 8 channels  |
| Compression            |         | G.711  |
| Audio Support          |         | Two-way  |
| Management             |         |  |
|                        | Trigger | Schedule, Sensor Input, Motion Detection   |
|                        | 1118861 | Store Video (AVI format)   |
|                        |         | Send e-mails with captured images  |
| Event Management       | Action  | Upload captured images to FTP Server   |
|                        | Action  | Monitor through Center V2 and Vital Sign Monitor                                 |
|                        |         | Activate relay outputs to control external devices                               |
| Firmware Upgrade       |         | Remote upgrade by HTTP, Firmware upgrade utility                                 |
| Storage                |         | USB HDD Storage  |
| Client PC Requirements | s       | Microsoft Internet Explorer 8.x or later   |
| Security               |         | IP address filtering   |
| Scourcy                |         | Bulgarian / Czech / Danish / Dutch / English / French / German / Greek /         |
|                        |         | Hebrew / Hindi / Hungarian / Italian / Indonesian / Japanese / Norwegian /       |
| Language               |         | Lithuanian / Persian / Polish / Portuguese / Romanian / Russian / Serbian /      |
|                        |         | Simplified Chinese / Slovakian / Slovenian / Spanish / Thai / Traditional Chines |
|                        |         | / Turkish  |
| Network                |         |  |
|                        |         | 10/100/1000 Base-T Ethernet,   |
| Interface              |         | 802.11b/g/n Wireless LAN (optional),   |
|                        |         | Mobile broadband: UMTS, EDGE, etc. (optional)                                    |
| Drotocol               |         | DHCP, DynDNS, FTP, HTTP, HTTPS, 3GPP/ISMA, NTP, ONVIF (Profile S), RTSP,         |
| Protocol               |         | SMTP, SNMP, TCP, UDP, UPnP, QoS (DSCP)   |
| External Interface     |         |  |
| Video Input            |         | 8 BNC ports  |
| Audio Input            |         | 4 ports (stereo phone jack, 3.5mm/0.14")   |
| Audio Output           |         | 1 port (stereo phone jack, 3.5 mm/0.14")   |
| Sensor Input           |         | 8 inputs   |
| Alarm Output           |         | 8 outputs  |
| PTZ                    |         | RS-485 +/-   |
| Ethernet               |         | RJ-45, 10/100/1000 Mbps  |
| USB                    |         | 2 ports (USB 2.0)  |
| Power                  | Input   | DC Jack (DC 12V, 3.0A)   |
| Environment            |         |  |
| Operation Temp.        |         | -20°C ~ 50°C / -4°F ~ 122°F  |
| Humidity               |         | 0% ~ 90% RH (non-condensing)   |
| Weather Resistance     |         | Indoor use   |
| Physical               |         |  |
| Dimensions (L x W x H) |         | 200 x 175 x 40 mm / 7.87 x 6.88 x 1.57 in  |
| Weight                 |         | 0.95 kg / 2.09 lb  |
| Regulatory             |         | CE, FCC, RCM, RoHS compliant   |
| Applications           |         |  |
|                        |         | GV-VMS (V16.10.3.0), GV-DVR / NVR (V8.7.1.0), GV-Control Center (V3.4.0.0),      |
| Software Supported     |         | GV-Edge Recording Manager (V1.2.0.0), GV-Center V2 (V16.10.0.0),                 |
|                        |         | GV-Recording Server (V1.3.0.0), GV-Redundant / Failover Server (V1.1.0.0)        |
| Network Storage        |         | GV-DVR / NVR / VMS, GV-Backup Center, GV-Recording Server                        |
| Mobile Phone Support   |         | GV-Eye for iOS and Android   |
| Live Viewing           |         | IE, Firefox, Chrome, Safari, Edge  |
| CMS Server support     |         | GV-Control Center, GV-Center V2, GV-Vital Sign Monitor                           |





#### Note:

- 1. It is required to apply patch files to all the supported software mentioned above except GV-VMS and GV-Center V2.
- 2. GV-Video Server cannot work with microphones that acquire power from the unit. Use microphones that have external power supply.
- 3. GV-VS2800 supports 1 external hard disk (2.5" or 3.5") with up to 6 TB capacities.
- 4. It is not recommended to use the flash USB drive with GV-VS2800 because of its slow read and write speed.
- 5. Product design and specifications are subject to change without notice.

#### **Packing List**

- 1. GV-VS2800
- 2. AC Power Cord
- 3. Power Adaptor
- 4. Download Guide
- 5. Warranty Card

#### **Options**

Optional devices can expand your GV-Video Server's capabilities and versatility. Contact your dealer for more information.

| GV-Relay V2                | Working with a GV-Relay V2, the GV-Video Server is capable of driving the loads of relay outputs over 5 volts. |  |
|----------------------------|--|--|
| GV-WiFi Adaptor V2         | The WiFi Adaptor V2 is designed to connect GV IP devices, such as GV-Video Server, to the wireless network.    |  |
| 3.5 mm Stereo to RCA Cable | 3.5 mm Stereo to RCA Cable is served as an audio adapter for microphones with RCA connectors.                  |  |
| Wall Hook                  | Wall Hook is used to mount GV-VS2800 to the wall.  |  |
| DIN-rail Hook              | DIN-rail Hook is used to mount GV-VS2800 to a 35-mm (1.38-in) DIN rail.  |  |
| Rack Mount                 | Rack Mount is used to mount up to 2 video servers to a 19-in (482.6-mm) rack.                                  |  |

### **Supported Wireless LAN USB Adaptor**

| Vendors   | Model   |  |
|---|---|--|
| D-Link  | DWA-140 (H/W version B1), DWL-G122 (version C1) |  |
| EDIMAX  | EW-7318Ug, EW-7718Un, EW-7711UAn                |  |
| Linksys   | WUSB54GC, WUSB600 (version 1)                   |  |
| Pegatron  | WL-166N11                                       |  |
| Note: Linksys WUSB54GC ver. 3 is not supported. |   |  |





## **Supported Mobile Broadband Device**

| Vendors  | Model   |
|----------|---|
| Bandluxe | C320, C501  |
| D-Link   | DWM-222   |
| HUAWEI   | E156, E156B, E169, E220, E1692, E1750, E1752, E1756, E1756C, EC169C, EC189 USB Modem (HSDPA/UMTS/EDGE/GPRS/GSM) |
| Novatel  | MC950D, MC996D, MC998D (HSDPA/UMTS/EDGE/GPRS/GSM)   |
| Onda     | MSA523HS  |
| Sierra   | 250U  |
| Verizon  | USB727, USB728, USB760 Modem (EVDO)   |
| Vodafone | K3565 (Rev 2)   |
| ZTE      | MF100   |